


Metal Business Card holder Folding Instructions



Note: Most of the card holders may be bent so the object is facing left or right.



- Step 1: Lay your cardholder face down on a hard flat surface that has a straight edge with the lines marked "First Bend" lined up with the edge.
- Step 2: Holding your card holder with one hand, push the bottom portion down until it starts to bend. (See Side View 'A.')
- Note: Do not over bend, as it will be harder to start your next bend.
- Step 3: Move your card holder so the position marked "Second Bend" is lined up with the edge of your hard flat surface.
- Step 4: Holding your card holder with one hand, push the bottom portion down until it starts to bend. (See Side View 'B')
- Note: Continue to bend until it has about an 86° angle.
- Step 5: Pick up your card holder, and bend the half round tab the opposite direction until it is straight with your previous bend.
- Step 6: Adjust your card holder until it looks similar to Side View 'C' from the side. Note you want the back of your cardholder to have a slight angle toward the back, so your cards don't lean forward.